







► Reverse Gear Detection

Our vehicle computer can obtain information whether the vehicle is in reverse mode or not. The reverse gear will be activated with the signal received from both the CAN bus or the vehicle's reversing lamp. When the reverse gear signal is received from the reverse gear or from the reverse lamp, the display will be activated and will be showing the rear view of the machine.





